

F 900A/1000AXP.24

use and maintenance

FROM SERIAL NUMBER *1001*

INDEX

- 1 INTRODUCTION
- 2 CLASSIFICATION OF THE CRANE MODEL
 - 2.1 Generality
 - 2.2 Hydraulic jibs
 - 2.3 Technical data
- 3 CAPACITY PLATES
 - 3.1 Generality
- 4 HYDRAULIC SCHEMATICS
- 5 ELECTRIC SCHEMATICS
- 6 SAFETY NORMS
- 7 WARNING AND INSTRUCTIONS
 - 7.1 Generality
 - 7.2 Before operating
 - 7.3 During operation
 - 7.4 At the end of the operation (Prior to driving the vehicle)
 - 7.5 Residual risks
- 8 IDENTIFICATION OF THE CRANE MODEL
 - 8.1 Generality
 - 8.2 Crane mark
- 9 CRANE NOMENCLATURE
 - 9.1 Controls for crane and outriggers through push-button panel of the radio remote control
- 10 NOMENCLATURE OF THE SAFETY AND PROTECTION DEVICES
 - 10.1 Controls for crane and outriggers through push-button panel of the radio remote control
- 11 SUPPLEMENTARY BEAMS
 - 11.1 Generality
 - 11.2 Identification of the supplementary beams
- 12 TILTABLE OUTRIGGER RAMS
 - 12.1 Manually tiltable outrigger rams
- 13 MANOEUVRES AND CONTROLS TO STABILIZE THE VEHICLE
 - 13.1 Generality
 - 13.2 Functions of control levers for stabilization
 - 13.3 Controls to stabilize the vehicle
 - 13.3.1 Crane with fixed or manually tiltable supports for outrigger rams
 - 13.3.2 Crane with hydraulic tiltable supports (WITH CHAIN) for outrigger rams
- 14 CONTROLS TO OPERATE THE CRANE
 - 14.1 Generality

- 14.2 Manoeuvres to unfold the crane into a working condition
- 14.3 Manoeuvres to fold the crane into the rest condition
- 15 MANOEUVRES OF THE CRANE LOADS (version with load limiting device) (not available)
- 16 MANOEUVRES OF THE CRANE LOADS (version with lifting moment limiting device)
 - 16.1 Generality
 - 16.2 Lifting moment limiting device "ELECTRONIC"
 - 16.3 Control panel
 - 16.4 Load handling
 - 16.5 Lifting moment limiting device for two working sectors
 - 16.6 Rotation limiting device
 - 16.7 In the case of the appearance of the signal "ALARM" on the display of the control panel or of the radio remote control or in case of an electrical failure
 - 16.7.1 Diagnostic (Alarms/Input/Output) LME vers. 4-5 UC 01-7
 - 16.7.2 Temporary OVERRIDE-Reactivation for the crane functions in case of the appearance of the signal "ALARM" on the display of the push-button panel
 - 16.7.3 Temporary OVERRIDE-Reactivation for the crane functions in case of an electrical failure, out of order of the radio remote control, or of the appearance of the signal "ALARM" on the display of the push-button panel (in this case, we cannot reactivate the crane functions)
 - 16.8 XP device (if fitted, see the Use and Maintenance booklet)
 - 16.8.1 Activation and instructions for use of the XP/V device (if fitted, see the Use and Maintenance booklet)
 - 16.9 IMC and ADC devices (if fitted, see the Use and Maintenance booklet)
- 17 USE OF IMPLEMENTS
 - 17.1 Generality
 - 17.2 Hydraulic connections for implements - supplementary hoses
 - 17.3 Oil cooler (heat exchanger)
- 18 MANUAL EXTENSIONS
 - 18.1 Generality
 - 18.2 Lifting moment limiting device "ELECTRONIC" for the manual extensions (valid starting from the version 3.0 of the software) (if fitted)
- 19 CONTROLS TO OPERATE THE HYDRAULIC IMPLEMENTS OF THE CRANE (not available)
- 20 HYDRAULIC JIBS
 - 20.1 Generality
 - 20.2 Identification of the hydraulic jib
 - 20.3 Nomenclature of the hydraulic jib
 - 20.4 Manoeuvres to unfold the jib in working condition
 - 20.5 Manoeuvres to fold the jib in rest condition
 - 20.6 Operations to remove the hydraulic jib from the crane
 - 20.7 Operations to mount the hydraulic jib on the crane
- 21 WINCH
 - 21.1 Generality
 - 21.2 Winch for crane
 - 21.2.1 Winches equipped with a mechanical stroke end device
- 22 MAINTENANCE INSTRUCTIONS
 - 22.1 Generality
 - 22.2 Timer
 - 22.3 After every 8 working hours or at the end of every working day
 - 22.4 After every 40 working hours or after every working week
 - 22.5 After every 100 working hours or more frequently in case of more intensive utilisation
 - 22.6 After every 500 working hours or after every 6 working months
 - 22.7 After every 1000 working hours or after every working year
 - 22.8 Complete overhaul of the crane is required when 10.000 working hours or 10 years' life are reached
 - 22.9 Instructions for the dismantlement and the demolition of a FASSI crane
- 23 TABLE OF HYDRAULIC OIL AND LUBRICANTS CHARACTERISTICS
- 24 POSSIBLE FAULTS
 - 24.1 Generality
 - 24.2 Only operations which can be carried out by the user
 - 24.3 Operations to be carried out only by a service center
- 25 INSTRUCTION AND WARNING PLATES

use and maintenance

THANK YOU FOR SELECTING ONE OF FASSI CRANES.

This crane is the result of **FASSI** philosophy: ongoing research, rigorous testing, data verification, and analysis of performances.

Many years of experience has allowed us to grant you the maximum safety of operation together with the optimization of machine performances.

All this represents the core of **FASSI quality system**.

**FASSI quality system is in conformity with
UNI EN ISO 9001:2000 (ISO 9001:2000)**

FASSI cranes conform with the European Norm EN12999

The fitment of the crane on the vehicle must be carried out in accordance with the instructions given by **FASSI** in the manual for hydraulic crane fitting and the relevant chassis manufacturers directives.

The Manufacturer declines all responsibility and guarantee if the fitting is entrusted to workshops without sufficient technical capability to carry out the work in conformity.

Be sure that the unit has been installed, inspected and tested in accordance with the local legal requirements.

As well as the principal safety norms, this manual contains a description of the crane and the instructions for use and maintenance.

The following instructions refer to mobile cranes in general and must be integrated with the manual for use supplied by the centre responsible for the crane fitting on truck, vehicle or other type of structure.

READ THIS MANUAL CAREFULLY prior to use or any maintenance. A few minutes spent now could save time and labour later.

Always conform to the safety norms and the instructions for use and maintenance contained in the present manual in order to guarantee a long life to the crane.

NOTE

The original version of the present manual is in italian.

The spare parts catalogue for the crane can be viewed in the Internet site: www.fassicat.com

2 CLASSIFICATION OF THE CRANE MODEL

2.1 Generality

The design of this crane has been carried out in respect of fatigue test classification **H1B3** of the **EN12999** norm.

The crane can operate, intermittently, with lifting devices other than the hook.

The dimensions and the capacity of the implements must be proportioned with crane performances.


2.2 Hydraulic jibs


Hydraulic jibs							
Extension type	Weight=kg	Manual	Weight=kg	Manual	Weight=kg	Manual	Weight=kg
L804	2100	PL80	74	QL80	64	RL80	46
L805	2300	PL80	74	QL80	64	RL80	46

2.3 Technical data


F 900A/1000AXP.24

Lifting capacity	Standard reach	Hydraulic extension	Rotation arc	Rotation torque	Working pressure	Pump capacity	Oil tank capacity	Crane weight	Max. working pressure on the outrigger (Φ 210)
87,1 tm 854,4 kNm 629.996 lbf.ft	12,10 m 39'8" ft/in	7,50 m 24'7" ft/in	360° continuous	10,19 tm 100 kNm 73.704 lbs.ft	32,5 MPa 4.714 psi	80 l/min 21,13 gal/min	280 l 73,97 gals	7550 kg 16.645 lbs	81,3 daN/cm² 1.179,16 psi



F 900A/1000AXP.24

— MEZZERIA TIRANTI
— FIXING ROD CENTER DISTANCE
— LIGNE MEDIANE TIRANTS
— ABMESSUNG DER BEFESTIGUNGSBRIDEN
— DISTANCIA ENTRE ESPÁRRAGOS
— LINHA MEDIANA DOS TIRANTES
M39 x 3

FASSI ST 900**F 900A/1000AXP**

	A		B	
F900A.22	2455	8'1"	3435	11'3"
F900A.23	2370	7'9"	3275	10'9"
F900A.24	2215	7'3"	3015	9'11"
F900A.25	1745	5'9"	2480	8'2"
F900A.26	1630	5'4"	2315	7'7"
F900A.27	1500	4'11"	2140	7'0"

MASSIMA ALTEZZA SOTTOGANCIO.
HAUTEUR MAXIMUM SOUS CROCHET.
MAXIMUM HOOKING POSITION.
MAXIMALHOEHE BIS KRANHAKEN.
MÁXIMA ALTURA DEBAJO DEL GANCHO.
ALTURA LIVRE MÁXIMA DEBAIXO DO GANCHO.

FASSI**FASSI ST 900**


3.1 Generality

The represented plates refer to the nominal design capacities.


(!) WARNING (!)

If the capacities are downgraded or partially reduced (e.g. sector in front of vehicle cab) capacity plates must be applied in line with the final test figures.



3.1-1 Capacity plates with lifting moment limiting device




3.1-1 Capacity plates with lifting moment limiting device




3.1-1 Capacity plates with lifting moment limiting device




3.1-1 Capacity plates with lifting moment limiting device




3.1-1 Capacity plates with lifting moment limiting device




3.1-1 Capacity plates with lifting moment limiting device




3.1-1 Capacity plates with lifting moment limiting device




3.1-1 Capacity plates with lifting moment limiting device




3.1-1 Capacity plates with lifting moment limiting device




3.1-1 Capacity plates with lifting moment limiting device




3.1-1 Capacity plates with lifting moment limiting device



3.1-1 Capacity plates with lifting moment limiting device




Hydraulic schematic for crane - Danfoss distributor - "electronic" lifting moment limiting device



CODE DESCRIPTION



D1776	DISTRIBUTOR	VA148	ELECTRIC MAIN WITH BY PASS VALVE
DV015	DEVIATOR	VA185	SELECTOR VALVE
EV124	ELECTROVALVE	VA194	DOUBLE EFFECT BLOCK VALVE
EV128	ELECTROVALVE	VA203	SIMPLE EFFECT BLOCK VALVE
F1776	OIL FILTER (HIGH PRESSURE)	VA204	DOUBLE EFFECT BLOCK VALVE
F1870	OIL FILTER (RETURN)	VA205	DOUBLE EFFECT BLOCK VALVE
M1/M2	GAUGE QUICK CONNECTION	VA217	SEQUENCE VALVE
MT133	MOTOREDUCTOR	VA227	SEQUENCE VALVE
PR103	PRESSURE SWITCH	VA232	UNIDIRECTIONAL VALVE
RU977	FAUCET	VA239	SIMPLE EFFECT BLOCK VALVE
RU978	FAUCET	VA246	REGENERATIVE VALVE
SC002	OIL COOLER (HEAT EXCHANGER)	VA249	UNIDIRECTIONAL VALVE
TR001	PRESSURE TRANSDUCER	VA256	OIL FLOW REGULATOR VALVE FOR ROTATION CYLINDER



CODE DESCRIPTION

DI420	DISTRIBUTOR
DV015	DEVIATOR
TR001	PRESSURE TRANSDUCER
VA102	DOUBLE EFFECT BLOCK VALVE
VA164	DOUBLE EFFECT BLOCK VALVE
VA175	BLOCK VALVE + FAUCET
VA185	SELECTOR VALVE
VA187	BLOCK VALVE + FAUCET
VA194	DOUBLE EFFECT BLOCK VALVE
VA212	DOUBLE EFFECT BLOCK VALVE
VA215	OIL FLOW CHECK VALVE
VA232	UNIDIRECTIONAL VALVE

Electric schematic for crane



N°	DESCRIPTION
ALIM	GENERAL FEEDING
ALIM1	SHUNT BOX ON THE COLUMN
ALIM2	SHUNT BOX ON THE BASE
D1...D10	CONNECTORS FOR DANFOSS MODULUS
DR	ELECTRIC ROTATING DISTRIBUTOR
EM	EMERGENCY
EV1	ELECTROVALVE FOR CRANE BLOCK
EV2	ELECTROVALVE FOR LIFTING MOMENT LIMITING DEVICE OF THE TWO WORKING ZONES
EV3	XP ELECTROVALVE
EV4	ELECTROVALVE FOR PRESSURE REDUCTION OF REGENERATIVE EXTENSION EXIT
EV5	REGENERATIVE ELECTROVALVE
EVDEV	ELECTROVALVE FOR ELECTRIC DEVIATOR CRANE/OUTRIGGERS
EVE1/2/3/4	EXTENSION ELECTROVALVE
EVG	GENERAL ELECTROVALVE FOR OUTRIGGER DISTRIBUTOR
EVR	RE-ENTRY ELECTROVALVE OUTRIGGERS/EXTENSIONS
EVS1/2/3/4	OUTRIGGER ELECTROVALVE
EVU	EXIT ELECTROVALVE OUTRIGGERS/EXTENSIONS
FX003	DANFOSS CONTROL UNIT
FX004	OUTRIGGER CONTROL UNIT
IP1/2/3	PROXIMITY MICROSWITCH FOR ROTATION CONTROL
LCV	WINCH LOAD LIMITING DEVICE
LG	90% LOAD YELLOW WARNING LIGHT
LP	FLASHING
LR	ACTIVATION OF OVERLOAD BLOCK RED WARNING LIGHT
M1...M7	MICROSWITCH ON THE DISTRIBUTOR
MS	MERCURY LEVEL SENSOR ON THE OUTER BOOM
MV1	PULLEY MICROSWITCH FOR WINCH (FITTED ONLY ON THE ELECTRIC STROKE END)
MV2	DRUM MICROSWITCH WINCH
P1	PRESSURE SWITCH FOR THE RE-ENTRY OF THE EXTENSION BOOMS
S25	SELECTOR FOR ACTIVATING SECOND MS FOR THE HYDRAULIC JIB AT 25°
RADIO	RECEIVER OF THE RADIO REMOTE CONTROL
TP1	PRESSURE TRANSDUCER FOR INNER RAM
TP2	PRESSURE TRANSDUCER FOR OUTER RAM
TP3	PRESSURE TRANSDUCER FOR THE JIB RAM
UCF	GENERAL CONTROL PANEL (FX000)

6 SAFETY NORMS

Strictly conform to the norms reported by the plates DE2499B (fig. 1) or DE4236 (fig. 1a) placed next to the controls, in order to avoid possible accidents while operating the crane.

Only authorized persons are allowed to operate the crane.

The crane must be used on firm, level ground.

Check that the vehicle hand brake is on and that the wheels are chocked.

Before every operation make sure that:

- no-one is within the working area of the crane;
- the safety devices are in place and operative;
- the minimum safe working distances from power lines are observed;
- the load is correctly slung and hooked.

Stabilize the vehicle by the outrigger rams, making sure that:

- the lateral supports are fully extended;
- the wheels are in contact with the ground and the suspension is not completely unloaded.

Use the crane in accordance with the use and maintenance manual, making sure that:

- the load and radius are within the maximum limits shown on the crane capacity plate;
- the crane is used progressively avoiding sudden load movements
- swinging or dragging of the load is avoided;
- the load is lifted before rotating.


When using implements protect the crane working area with a barrier.

The vehicle/crane are not left unless the power take off is disengaged and the load is on the ground.

Before driving the vehicle make sure that the outriggers are fully retracted and re-entered, the safety taps closed and the crane is in folded position.

VERTICAL VERSION

fig. 1

**FASSI**
GRU IDRAULICHE

FASSI GRU IDRAULICHE SpA
24021 ALBINO (BG) ITALIA - Via dei Carmelitani, 2
Tel. + 39 35 77.64.00 - Fax + 39 35 75.50.20


DE2499B

INSTRUCTIONS FOR SAFE USE OF THE CRANE

- 1 Only authorized persons are permitted to operate the crane.
- 2 The crane must be used on firm, level ground.
- 3 Check that the vehicle hand brake is on and that the wheels are chocked.
- 4 Before operation make sure that:
 - no-one is within the working area of the crane;
 - the safety devices are in place and operative;
 - the minimum safe working distances from power lines are observed;
 - the load is correctly slung and hooked.
- 5 Stabilize the vehicle with the outriggers, making sure that:
 - the lateral supports are fully extended;
 - the wheels are in contact with the ground and the suspension is not completely unloaded.
- 6 Use the crane in accordance with the use and maintenance manual, making sure that:
 - the load and radius are within the maximum limits shown on the crane capacity plate;
 - the crane is used progressively avoiding sudden load movements;
 - swinging or dragging of the load is avoided;
 - the load is lifted before rotating.
- 7 When using implements protect the working area with a barrier.
- 8 The vehicle/crane are not left unless the power take off is disengaged and the load is on the ground.
- 9 Before driving the vehicle ensure that the outriggers are fully retracted and re-entered, the safety taps closed and the crane is in the folded position.

HORIZONTAL VERSION

fig. 1a

**FASSI**
GRU IDRAULICHE

FASSI GRU IDRAULICHE SpA
24021 ALBINO (BG) ITALIA - Via dei Carmelitani, 2
Tel. + 39 35 77.64.00 - Fax + 39 35 75.50.20

DE4236

INSTRUCTIONS FOR SAFE USE OF THE CRANE

- 1 Only authorized persons are permitted to operate the crane.
- 2 The crane must be used on firm, level ground.
- 3 Check that the vehicle hand brake is on and that the wheels are chocked.
- 4 Before operation make sure that:
 - no-one is within the working area of the crane;
 - the safety devices are in place and operative;
 - the minimum safe working distances from power lines are observed;
 - the load is correctly slung and hooked.
- 5 Stabilize the vehicle with the outriggers, making sure that:
 - the lateral supports are fully extended;
 - the wheels are in contact with the ground and the suspension is not completely unloaded.
- 6 Use the crane in accordance with the use and maintenance manual, making sure that:
 - the load and radius are within the maximum limits shown on the crane capacity plate;
 - the crane is used progressively avoiding sudden load movements;
 - swinging or dragging of the load is avoided;
 - the load is lifted before rotating.
- 7 When using implements protect the working area with a barrier.
- 8 The vehicle/crane are not left unless the power take off is disengaged and the load is on the ground.
- 9 Before driving the vehicle ensure that the outriggers are fully retracted and re-entered, the safety taps closed and the crane is in the folded position.

7 WARNING AND INSTRUCTIONS

7.1 Generality

The use of the crane is reserved to authorized personnel, instructed in advance, who has to conform to the safety norms and instructions contained in the use manual supplied with the crane. (See norms ISO 9926-1)

It is absolutely prohibited to walk or stop under a suspended load


It is prohibited for unauthorized persons to be within the working area.

Under no circumstances interfere with the safety and protection devices.

Warning plates, as well as instruction and operation plates must be replaced when no longer readable or missing. See Paragraph 25 Instruction and warning plates.

Do not use the outriggers to raise the vehicle.

To avoid hitting bridges or tunnels check and record the overall height of your crane in the folded position or in laid position in the body or on the load. Always respect and pay proper attention to road signs placed in proximity of such obstacles.





7.2 Before operating

(!) ATTENTION (!)

Check that protections are in their place and that all safety devices are fitted and active. (See norms ISO 9927-1)

Keep the ladder and the control station on the top seat, clean; the seat can tilt forward.

Make sure that control stations are properly lit so as to ensure safety while operating and allow instruction plates to be visible.



Check that the working area is adequate and properly lighted for your crane.

Make sure that the hook is always free to rotate on its pin and that nothing obstructs its vertical positioning.

Check the efficiency of the hook safety catch.

Carefully inspect the condition of ropes or chains.

Make sure that the pallet fork is connected to the crane hook by means of a chain having at least **three (3)** rings.

7.3 During operation


Take the vehicle fumes away from the working area by fitting an extension tube of a suitable diameter to the exhaust system.

Do not run the engine in a indoor area without first making sure there is adequate ventilation.

When using the ladder to reach the control station on the top seat, avoid knocking into the controls while going up or down the ladder.

The control station on the top seat is provided with side safety guards; stay within these guards.

Make sure that no one is within the working area of the crane.











(!) ATTENTION (!)

Avoid swinging the load above working and transit areas; any hidden danger situation must be audibly alarmed.

Avoid all those situations which may result in crushing during vehicle stabilization, crane movement and load handling.

(In conformity with EN 349 standard the minimum safe working distances to avoid crushing parts of the body)

Parts of the Body	Minimum safe working distance mm	Figure	Parts of the Body	Minimum safe working distance mm	Figure
Body	500		Head	300	
Leg	180		Foot	120	
Toes	50		Arm	120	
Hand Wrist Fist	100		Finger	25	




The table indicates the minimum safety working distances concerning the various parts of the body.

The figures illustrate circumstances which may turn out to be dangerous if you fail to respect the minimum safe distances and if it is impossible to introduce larger parts of the body.

(!) ATTENTION (!)

Failure to respect the minimum safe distances may result in a safety hazard and a deadly risk.



Remember that the stability of the unit (crane-vehicle) is only guaranteed by the complete lateral extension of the outriggers and by the observance of the capacity plates.



Stabilize the vehicle on a horizontal plane with a maximum tolerance of 1,5 degrees. Make sure that the outrigger rams rest on a solid base, if necessary use larger outrigger base plates (available on request) to avoid sinking. If you adopt other means, make sure that they are suitably sized for the load they must bear.

(!) ATTENTION (!)

Respect the distances di sicurezza from electric lines; the minimum distance is, according to CEN norms, five (5) meters, except for otherwise prescribed by national norms.



(!) ATTENTION (!)

Failure to respect the minimum safe distances may result in electrical hazards for the operator and his assistants.

ELECTRICUTION:


General safety precautions for the operator and potential co-workers. If the crane hits an overhead power line, do not touch the crane, the truck or the load.

Carefully evaluate the danger before moving. If you are closer than 10 meters from the crane, the truck, the load or the electric line, move at least 10 meters away, by shuffling away with small steps, in order to minimize the chance of getting a too high voltage difference between the feet.

Warn others to stay away; call for help and contact the power company to de-energize the line: do not attempt to assist someone in direct or indirect contact with the power line before the power has been disabled: you run the risk of being electricuted yourself.

If you are in the truck cabin, stay inside without touching the vehicle body because it's extremely hazardous to go out before the line is de-energised.

Help the electricuted person if you know the first-aid procedures, otherwise wait for the paramedics to arrive.

**(!) ATTENTION (!)**

Do not utilize the crane during thunderstorms and with wind speed exceeding 13,8 m/s (50 km/h), maximum value of the Beaufort scale degree 6.

Indications about wind speed

Force of the wind Beaufort scale	Wind speed m/s	Classification	Characteristics
0	0,0 - 0,2	Calm	Calm wind, smoke goes up quite vertically
1 2	0,3 - 1,5 1,6 - 3,3	Light breeze	Smoke reveals the direction of the wind, one can feel the wind blowing, leaves start fluttering.
3 4	3,4 - 5,4 5,5 - 7,9	Moderate breeze	Leaves and branches are in constant motion, small branches start fluttering. Dust and papers dance on the ground.
5	8,0 - 10,7	Fresh breeze	Small green branches bend, the surface of waterways and lakes are wavy.
6	10,8 - 13,8	Near gale	Big branches bend, wind whistles through high-tension cables, it's difficult to walk keeping the umbrella open.
7	13,9 - 17,1	Moderate gale	Trees sway, it's hard to walk
8	17,2 - 20,7	Storm wind	Branches get broken, it's hard to walk.
9	20,8 - 24,4	Storm	It damages houses (antennas and roof tiles fall down)



(!) ATTENTION (!)**Carefully inspect the load rigging.**


Hook up the load, checking that it does not exceed the capacity indicated on the lifting diagram specific to each load configuration.

Make sure that the lifted load is balanced.

Avoid swinging the load above the control station; in cases where the load is too close, the crane must be operated from the opposite side.

When operating through a winch, lift the load vertically using the cable and not the booms in order to avoid swinging the load.






Do not rotate the crane before the load is lifted.

Do not operate with sudden movements, activate the controls with slow and progressive movements; rotate slowly and with care paying attention to the stability of the vehicle.

With vertical lift, on hydraulic and mechanical extension, rotate slowly in order to avoid side-skidding.




(!) ATTENTION (!)

Do not utilize the crane for pushpull (F), lateral (F) or sideways (F) operations.

(!) ATTENTION (!)

Crushing (F) or push (F) manoeuvres are not permitted.



(!) Never operate the outriggers when the crane is loaded.

(!) ATTENTION (!)

The vehicle\crane must not be left unless the load is on the ground, the booms of the crane (and of the hydraulic jib), are folded and laid on a solid base and the power take-off is disengaged.

Do not move the vehicle with the crane not in transport position and not with a load suspended on the crane.

7.4 At the end of the operation (Prior to driving the vehicle)

Fold the crane.

If the booms of the crane (or of the hydraulic jib) are to be laid on the body or on the load, they must be suitably blocked to prevent possible sideways movements.

Make sure that the indications about the overall dimensions are respected.


NOTE

Implements can be left mounted on the booms of the crane (or of the hydraulic jib) only if the overall dimensions are respected; they must be suitably blocked to prevent possible sideways movements.

If an accessory (fork, ...) is mounted, it must be tied down at all times during transport.

Make sure that the outrigger supports and rams are re-entered within the overall width of the truck and locked by the safety devices.

Disengage the power take off.



7.5 Residual risks

Note: This reasoned list does not carry the complete list of the residual risks, which are examined more in detail paragraph by paragraph in the manual under "**(!) ATTENTION (!)**"; it is instead a way to exemplify to the operator the types of hazards linked to the use of the crane, which basically involves a lifted load in movement. Therefore we confirm you the following

It is absolutely forbidden to use the crane without having read and understood the manual for use and maintenance and without having being previously instructed by experienced personnel on all aspects of safe crane operation.

Risk evaluation shall be followed by adequate provisions in order to avoid risks and damages to people and things.

The crane operator shall be held directly responsible for the correct operation of the crane also according to the jobsite conditions.

Overturn: the crane can overturn, thus hurting people and damaging things

- if it is not correctly stabilized
- if the moment limiting device is voluntarily disabled
- if the ground conditions at the jobsite are not stable enough with respect to the dimensions of the outrigger base and/or of the additional base plate.

Moment limiting device: never try to bypass nor tamper with the moment limiting device and the various safety systems installed on the crane. In such case the operator shall be held responsible for the subsequent crane performance. It is also important to understand the alarm messages generated by the "moment limiting device" and act consequently.

Control seat: before operating from the control seat the operator shall make sure that he's safe from hazards (i.e. he stands clear of the load, there is a way of escape,...). Otherwise he shall manoeuvre from a different control seat; if there is none available, the crane should be equipped with a radio control or remote control in order to allow the operator to operate the crane in absolute safety.

From the control seat the operator shall be able to visually inspect the whole working area at all times. If it is not possible he shall team up with a co-worker able to control the whole area; otherwise the crane shall be equipped with a radio control in order to ensure the operator with the perfect position to see all potential hazards clearly at all times.

Load rigging: carefully inspect the load rigging; the operator shall make sure that the load is properly attached and balanced and that all unexpected movements are not allowed. Be careful not to hit any potential impediments during the crane movements.

Jobsite conditions: prior to use always ascertain that the working area is free and clear of potential obstacles to crane operations (people, building walls, balconies, eaves, scaffoldings, tree branches, other lifting means or machines,...). This may hurt people, damage both the impediments and the crane, and provoke also the crane overturn.

Make sure that there is no risk of elements falling on the operator or on the crane and take the right precautions to prevent it.

Overload and/or fatigue: the crane can break down due to fatigue or overload:

- If it is misused (with cycles or loads not pertinent to the crane class)
- If it is used for improper tasks (side, oblique or reversal pull)
- If it is used in poor jobsites (corrosive environment, too high or too low temperature, foundry,... [see conditions of use])
- If the load exceeds the rated capacity indicated on the relevant plates

Wrong manoeuvring: the crane can fall break or overturn if the operator performs a wrong manoeuvre due to the lack of familiarity with the operation procedures (see manual of use and maintenance) or due to inadequate psychophysical conditions: we remind you that the directives in force impose a suitable training of the personnel before using these types of machines and require an adequate psychophysical condition to operate safely a lifting device that always implies the intrinsic danger of a lifted load.

Weather conditions: too high or too low temperatures may damage the components of the oil, dynamic and electric circuits (See max and min conditions of use); it is forbidden to operate the crane during a storm with lightning hazards, so we recommend to fold it and put it to rest. Furthermore when the wind is too strong the crane can overturn or break down.

Shearing, entrapment: the crane has a lot of parts in movement that it is impossible to cover; therefore the operator shall always be aware of this residual risk and keep clear from the parts in movement, particularly from the load; the operator is held responsible not only for himself but also for those working in proximity of the crane and for those who may draw closer even if not authorized.

Electricution: the crane is not insulated from electric contacts and therefore it is not equipped to work under tension, even if the contact is accidental. Therefore be compliant with the min clearance prescribed by the national directives in force. Generally speaking the clearance from electric lines with a max tension of 38.000 volts should be at least 5 meters: Higher tensions require higher clearance to be verified case by case together with competent technicians and with respect to the environment conditions.

Manual extension overload: manual extensions are controlled by the moment limiting device only under the conditions described in the relative chapter; the control system of the manual extension overload must be activated by the operator as described.

Accessories: be careful when assembling and disassembling the accessories (extensions, buckets, baskets,...); first verify the weight, the securing systems and the instructions for assembly and dismantlement; then appraise their barycentre and provide for adequate provisional blocking systems in order to avoid sudden movements.

Breakdown of some sensors

The system "moment limiting device - intelligent type" is always monitored during ignition (the system, after having activated the various circuits, checks the presence of all the inputs for around 4 seconds) and then continuously monitors the operation and the efficiency of the limiting device (approx. every 25 milliseconds).

For most of the components the system checks also the congruence of the incoming signal with the one the system expects.

Maintenance: maintenance is particularly important; the lack of it may damage things or hurt people.

Particular operations: if you are required to operate under particular conditions not illustrated in the manual of use and maintenance, analyse carefully the situation and always refer to an authorised Fassi shop or to the Fassi technical support service or to experienced operators before starting working.

8 IDENTIFICATION OF THE CRANE MODEL

8.1 Generality

The exact **crane model**, **serial number** and description of **implements** will enable **FASSI Service Department** to give a rapid and efficient response.

8.2 Crane mark

The CE indicates that the crane complies with the Machines Directive (D.M.) 98/37; it can be considered effective only with a written declaration of conformity enclosed. The crane affixed with the CE mark is supplied with a lifting moment limiting device to preserve the crane structure from overloads.

Identification data are marked on the plate DE5891 used for the CE mark (fig. 2) and rivetted on the base with personalized rivets FASSI.




fig. 2

- 1 - Crane model
- 2 - Serial Number
- 3 - Year of manufacturing

The crane must not be put into service within the European Community unless the machine on which it is mounted also conforms with the prescribed Directive. Ever change of use, modification or addition of accessories, not specified by this manual must be affixed with a new CE mark in accordance with the Machinery Directive.



A further metallic plate (fig. 3) fixed to the crane by the installer, quotes the identifying data of the equipment and the final CE mark.

- 1 - Name of the installer who applied the final CE mark
- 2 - Crane mark, model and serial number
- 3 - Vehicle mark, model and chassis number
- 4 - Year of mounting




fig. 3

(!) **UNDER NO CIRCUMSTANCES SHOULD THE DATA MARKED ON THE PLATES BE ALTERED.**

9 CRANE NOMENCLATURE

9.1 Controls for crane and outriggers through push-button panel of the radio remote control. (fig. 4).

Pos	Description
1.	Outrigger rams
2.	Outrigger supports
3.	Base
4.	Slew ring
5.	Rotation motoreducer
6.	Deviator crane - outriggers
7.	Dual control for deviator crane - outriggers
8.	Integrated group for outrigger controls
9.	Electric hydraulic distributor for crane
10.	Column
11.	Inner ram
12.	Inner boom
13.	Outer ram
14.	Outer boom
15.	Booms extension rams
16.	Extension boom sections
17.	Lifting hook
18.	Oil tank
19.	Manual extensions (optional)
20.	Heat exchanger
21.	Receive radio remote control
22.	Push-button panel (transmitting-console of the radio remote control)





fig. 4



10 NOMENCLATURE OF THE SAFETY AND PROTECTION DEVICES

10.1 Controls for crane and outriggers through push-button panel of the radio remote control. (fig. 5).

Pos	Description
1.	Check valves for outrigger rams
2.	Check valves for rotation control (flow regulators)
3.	Check valve for inner ram
4.	Check valve for outer ram
5.	Check valve for booms extension rams
6.	Lifting moment limiting device assembly
7.	Control panel
8.	Rotation limiting device
9.	Main pressure valve (outriggers)
10.	Main pressure valve (crane)
11.	Auxiliary valves (crane)
12.	Safety device for outrigger supports
13.	Hook safety device
14.	Exclusion tap lever
15.	Visual indicator yellow/red light

Before crane use check that safety and protection devices are fitted and active.

Under no circumstances interfere with the safety and protection devices.

Interference with the check valves and removal of the lead seal remove the Manufacturer and invalidate the warranty.

Use the ladder for the access to the top seat.




fig. 5

11.1 Generality

Supplementary beams are used in conjunction with the crane outriggers to ensure the vehicle stability during load handling.

Code	outrigger ram stroke mm	outrigger interaxis mm	extension type	Weight kg
750B055	520	5770	Hydraulic-"H" variable	840
750B053	520	6870	Hydraulic-"H" variable	930
750B054	340	5770	Hydraulic-"H" variable	810
750B043	340	6870	Hydraulic-"H" variable	900
1400A143	415	8500	Hydraulic-"H" variable	1250

11.2 Identification of the supplementary beams

Identification data of the supplementary beam is punched on the beam (fig. 6) in the following sequence:

Ex. * 1400A143*0001

serial no.
identification code




fig. 6

12.1 Manually tiltable outrigger rams

Outrigger rams are allowed to be stored in an inclined position, when obstructions on the vehicle chassis prevent their vertical stowability. These hinged supports are placed between the outrigger supports and the rams; the fixed part is screwed to the supports while the mobile part is screwed to the rams. (fig. 9-9a)

To place the rams in a working condition.

- Supporting the ram, remove the check pin and the locking pin from their positions.
- Position, carefully, the ram in working condition, insert the locking pin in its new position and secure it with the check pin.

To re-position the rams to the folded position.

- Remove the check pin and the locking pin.
- Position, the ram in a upward direction and supporting the ram, insert
- the locking pin in its new position and secure it with the check pin

(!) The locking pin is constructed from special material

- **do not replace it with a non original part**
- **your security depends on it**



fig. 9



fig. 9a

13.1 Generality

The outriggers rams prevent damaging stresses both to the frame and to the vehicle suspensions on which the crane is mounted to and assure the stability of the unit during load handling.

(!) ATTENTION (!)

Be very careful when stabilizing the vehicle; make sure that no one is or transits in close proximity of the working area of the outriggers.

(!) ATTENTION (!)

The crane stability is maintained by the maximum extension of the outrigger supports, by the solidity of the base underneath the plates of the outrigger rams and by the observance of the capacity plates. To check the maximum working pressure see Paragraph 2.3 Technical data

Check that the outrigger rams are applied on a solid base; if necessary use larger outrigger base plates (available on request) to avoid sinking.

When stabilization is complete the wheels of the vehicle must still be in contact with the ground and the suspensions must not be fully unloaded.

Stabilize the crane so as to operate on a horizontal plane with a maximum tolerance of 1,5 degrees.

While loading, it may be necessary to vertically adjust the outrigger rams to prevent an overload on the outriggers, then stabilize again.

While unloading, the outrigger rams may not be perfectly in contact with the ground because of a rise in the suspension; it is therefore recommended to stabilize the vehicle during operation to avoid an overturn.

13.2 Functions of control levers for stabilization

The controls to stabilize the vehicle are activated only from the push-button panel of the transmitting-console.


(!) ATTENTION (!)


SINCE THE RADIO REMOTE CONTROL IS MOBILE, BEFORE STARTING MANOEUVRING OF THE STABILISERS WITH THE RADIO REMOTE CONTROL, THE OPERATOR SHALL MAKE SURE THAT THEIR MOVEMENTS ARE FULLY VISIBLE. DE5842

Selection crane-outriggers


(!) ATTENTION (!)

You can select whether to control the crane or the outrigger functions using the buttons placed on the remote control as follows:

To operate the outriggers, position the **A-B** selector (pos. 5) on **A** and the selector (**E/S** - ) (pos. 1) on **E/S**; then press together the left confirmation button (**OK**) (pos. 2) and the right confirmation button (**OK**) (pos. 6 for joy-stick controls, pos. 7 for linear controls). "Outriggers" appears on the display.

When turning on, the remote control asks for selector confirmation (**E/S** - ) on display; to confirm press contemporarily the two left-right (**OK**) confirmation buttons (pos. 2 and pos. 6 for joy-stick controls, pos. 7 for linear controls).

Functions of the controls on the push-button panel of the transmitting-console

The first 5 control levers on the push-button panel (beginning on the right) have two plates because they can control, through the selector (**E/S** - ) 5 functions of the crane or the functions for stabilization. Hereunder are reported the plates which correspond to the stabilization functions.

LINEAR PUSH-BUTTON PANEL SCANRECO





fig. 10

LEVERS CD



LEVER C



The three control joy-sticks on the push-button panel have two plates because they can control, through the selector (**E/S** - ) the functions of the crane or the functions for stabilization. Hereunder are reported the plates which correspond to the stabilization functions.

PUSH-BUTTON PANEL SCANRECO WITH JOY-STICK






fig. 10a

LEVERS CD



LEVER C



- Selector (**E/S** - ) Selector for the use of the crane or the outriggers.
- Levers **CD** Controls to select the outrigger supports and rams.
- Levers **C** Control of the selected outrigger support or ram.




fig. 11b




fig. 11

MANOEUVRES OF THE OUTRIGGER RAMS IN CASE OF AN ELECTRICAL FAILURE

In case of an electrical failure, electrical or hydraulic malfunctions, you cannot use the selectors on the push-button panel and so it is necessary to operate directly the integrated group of the outrigger control (fig. 11) after removing the protection.

PICTURE LIST (fig. 11):

G electrovalve for main bypass

U electrovalve for the ram descent and extension of the outrigger supports

R electrovalve for the ram re-entry and retraction of the outrigger supports

E1 E2 E3 E4 electrovalve of the extension rams

S1 S2 S3 S4 electrovalve of the outrigger rams

T electric deviator of the crane-outriggers (fig. 11a)

Example: re-entry of the outrigger ram **S1**

- tighten the **T** screw (fig. 11a)
- remove the lead seal placed on the electrovalve **G** (general), push the button and then turn it clockwise (fig. 11b pos. 1-2); the button stays in the closed position.
- Unscrew the knurled screw of the electrovalve **S1** of the outrigger.
- Push with an appropriate metal tip and in the direction of the arrow **F** the slider of the spool **R** (general) to re-enter the ram.
- **Re-screw the knurled screw of the electrovalve S1 of the outrigger.**
- **Put the button of the electrovalve G back to its original position, by turning it anti-clockwise (fig. 11b pos. 3-4)**
- to reactivate the crane functions loosen the **T** screw, to the previous position (see fig. 11a)

After such emergency operations and prior to re-use of the crane, you must immediately go to a FASSI authorised Center for the repair of the fault and re-sealing of the device.

- (!) Interferences with the valves or removal of the lead seal release the FASSI GRU IDRAULICHE from any responsibility and invalidate the warranty.


13.3 Controls to stabilize the vehicle

13.3.1 Crane with fixed or manually tiltable supports for outrigger rams

- Disengage the locking devices of the outrigger supports by putting the levers **A** from the position of the fig. 12 to the one of the fig. 12a.

- Position lever **D** of oil diverter () on **E/S**.

fig. 12b

- Position selector () of the push-button panel on **E/S**. (you read "outriggers" on the display)

- By using the levers **CD** and the lever **C** extend the outrigger supports and lower the outrigger rams till the complete stabilisation of the vehicle.

Example of using the levers **CD** and the lever **C**:

- extension of the outrigger support n°1

- activate the lever **CD** n°1 in the direction of **E**.

- by keeping activated the lever **CD** n°1, activate the lever **C** in the opposite direction.




fig. 12



fig. 12a

- descent of the outrigger ram n°1
 - activate the lever **CD** n°1 in the direction of **S**.
 - by keeping activated the lever **CD** n°1, activate the lever **C** in the opposite direction.

(!) ATTENTION (!)





The complete extension of the outrigger supports is visually indicated by the yellow triangles which are found at the end of the beam (and of the support if it's supplied with extra double extension beams). (Fig. 12b).

The stabilization has to be carried out with care and gradually keeping the vehicle in horizontal levelled condition to prevent springs overloads and chassis torsions.

(!) ATTENTION (!)

During the stabilising operations, for each outrigger ram, it is recommended to **DESCENT** the outrigger as the last manoeuvre.

To operate the crane controls, after having completed the stabilisation manoeuvres,

- Position lever **D** of oil diverter ( - **E/S**) on .
- Position selector ( -**E/S**) of the push-button panel on .

Manoeuvres for re-entry of the crane outriggers and supplementary outriggers within the overall vehicle width after crane use.

- Repeat by reversing the sequence of the operations effected for the stabilisation of the vehicle.

(!) ATTENTION (!)



Keep hands clear of automatic stop device of the outrigger supports (Fig. 12).

- (!)** Always check that the outrigger supports, once in their rest position, are locked in their seat by the safety devices, so as to assure the impossibility of accidental movement. (Fig. 12).

13.3.2 Crane with hydraulic tiltable supports (WITH CHAIN) for outrigger rams:

(!) ATTENTION (!)

Be very careful during vehicle stabilization operation; make sure that there are no obstacles preventing the rotation of the rams **and that no one is or transits in close proximity of the working area of the outriggers.**

- Disengage the locking devices of the outrigger supports by putting the levers **A** from the position of the fig. 12 to the one of the fig. 12a.
- Position lever **D** of oil diverter ( -**E/S**) on **E/S**.
- Position selector ( -**E/S**) of the push-button panel on **E/S**.
- By using the levers **CD**, the lever **C** and the valve taps, extend the outrigger supports, rotate the outrigger rams putting in a working condition and lower them till the complete stabilisation of the vehicle.

Example of using the levers **CD**, the lever **C** and the valve tap on the outrigger and the valve tap on the control ram for the tiltable support:

- **extension of the outrigger support n°1**
 - activate the lever **CD** n°1 in the direction of **E**;
 - by keeping activated the lever **CD** n°1, activate the lever **C** in the opposite direction.

- **rotation of the outrigger ram n°1 from the rest position (fig. 13) to the working condition (fig. 15)**
- make sure that the tap **R1** of the valve of the outrigger ram **S1** is closed (for the closed or opened position see fig. 14);
- open the tap **R2** of the valve of the control ram for the tiltable support;
- to remove the pin **2** proceed as follows:
 - activate the lever **CD** n°1 in the direction of **S**;
 - by keeping activated the lever **CD** n°1, activate the lever **C** in the opposite direction to control the rotation and take the ram **S1** to its rest position so that the pin **2** is extractable;
 - lift the parking pin **1** (safety) until it is released and remove from its seat the pin **2**;
- to rotate the outrigger ram **S1** proceed as follows:
 - activate the lever **CD** n°1 in the direction of **S**;
 - by keeping activated the lever **CD** n°1, activate the lever **C** in the opposite direction till the requested extension of the outrigger ram **S1**.




fig. 13

!!! ATTENTION !!!

Make sure that no one is or transits in close proximity of the working area of the outriggers.

- manually complete the rotation by positioning the ram vertically, insert the pin **2** in its new seat and lock it with the parking pin **1** (safety);
- close the tap **R2** of the valve of the control ram for the tiltable support

- (!) The locking pin 2 is constructed from special material**
- do not replace it with a non original part
 - your security depends on it

- descent of the outrigger ram n°1

- open the tap **R1** of the valve of the outrigger ram **S1**;
- activate the lever **CD** n°1 in the direction of **S**;
- by keeping activated the lever **CD** n°1 activate the lever **C** in the opposite direction till the requested extension of the outrigger ram **S1**;
- close the tap **R1** of the valve of the outrigger ram **S1**.

(!) ATTENTION (!)

The complete extension of the outrigger supports is visually indicated by the yellow triangles which are found at the end of the beam (and of the support if it's supplied with extra double extension beams). (Fig. 12b).




fig. 14

The stabilization has to be carried out with care and gradually keeping the vehicle in horizontal levelled condition to prevent springs overloads and chassis torsions.

(!) ATTENTION (!)

During the stabilising operations, for each outrigger ram, it is recommended to DESCENT the outrigger as the last manoeuvre.

To operate the crane controls, after having completed the stabilisation manoeuvres,

- Position lever **D** of oil diverter (-E/S) on .
- Position selector (-E/S) of the push-button panel on .

Manoeuvres for re-entry of the crane outriggers and supplementary outriggers within the overall vehicle width after crane use.

- Repeat by inverting the sequence of the operations effected for the stabilization of the vehicle.

(!) ATTENTION (!)

Keep hands clear of automatic stop device of the outrigger supports. (Fig. 12).

- (!) Always check that the outrigger supports, once in their rest position, are locked in their seat by the safety devices, so as to assure the impossibility of accidental movement. (Fig. 12).**




fig. 15

14.1 Generality






(!) WARNING (!)

Before operating the crane it is compulsory to set the outriggers. (Plate DE2327 fig. 16)



Radio remote control


The crane and hydraulic implements can be operated through proportional radio remote control subjugate to a distributor which the manual order is to be used only in case of emergency.

Display on the push-button panel of the radio remote control

- When you start the radio remote control (fig. 10), the pressure in the inner, outer ram and the jib and the percentage of load on the winch are displayed.
In relation to the view chosen like standard, when you start the radio remote control the pressure values are displayed in:
 - "bar" if on the display, on the left of the values, no symbol is present.
 - "daPsi" if on the display, on the left of the values, the symbol * is present.
- By pushing the button  the percentage values of pressure in the inner, outer ram and the jib and the percentage of load on the winch are displayed.
By pushing a second time the button  the pressure values in the inner, outer and jib rams movement in the measurement unit non standard and the percentage of load on the winch are displayed.
By pushing again the button  you return to the initial display.
- For the use of the control button  see Par. 22.2.
- By pushing the button  one or more times you return to the initial display (view of the pressure values).
- For the meaning of other messages see Par. 16.7.1 "Diagnostic".

You can select whether to control the crane or the outrigger functions using the buttons placed on the remote control as follows:

- To operate the crane, position the **A-B** selector (pos. 5) on **A** and the selector (**EIS-**) (pos. 1) on ; then press together the left confirmation button (**OK**) (pos. 2) and the right confirmation button (**OK**) (pos. 6 for joy-stick controls, pos. 7 for linear controls).
"Crane" appears on the display.

When turning on, the remote control asks for selector confirmation (**EIS-**) on display; to confirm press together the two left-right (**OK**) confirmation buttons (pos. 2 and pos. 6 for joy-stick controls, pos. 7 for linear controls).

Tele-radio remote control

The radio remote control, in the case of a discharged battery or in the presence of interference in the radio transmission, or use of the crane in situations where the transmission by radio is forbidden, it is easily transformed to cable remote control using a connecting cable.

Activation of the tele-radio remote control

- Connect by cable the remote control to the socket fixed on the base of the crane (fig. 17)

(!) WARNING (!)

First read the instructions given in the User's Manual supplied by the Manufacturer before using the remote control to avoid improper use.

The plates shown on the side of each push-button panel lever of the radio remote control and on each lever on the emergency control, determine the operation of the levers in relation to the movement of the crane.

(!) ATTENTION (!)

The sequence of the plates placed on the crane controls may be different.
Make sure that the lever you are going to operate correspond to the control you selected.

(!) Operate the levers smoothly and gradually (!)

When carrying out simultaneous movements of two or more functions, also related to pump flow and lever travel, it is possible that on reaching the stroke end of a particular function, an increase in speed of the other functions will occur.




fig. 16




fig. 17

LINEAR PUSH-BUTTON PANEL SCANRECO

ACCESSORY CONTROLS

CRANE CONTROLS





fig. 10



E/S 1 selector for the use of the outriggers (E/S) or of the crane ()

OK 2 exclusion push-button for the lifting moment limiting device

X 3 Y switching of the selector for the use of the 9°/10° function

XP ON 4 XP OFF selector for the use of the crane standard or XP

A 5 B selector for the use of the right control panel in configuration A or B

A 6 B = control button
+ RPM = GAS +


OK 7 A B = control button
- RPM = GAS -

8 = free

control button = 9 B = starting the engine

control button = 10 B = turning off the engine

PUSH-BUTTON PANEL SCANRECO WITH JOY-STICK



- E/S 1 selector for the use of the outriggers (E/S) or of the crane (8)
- 2 OK exclusion push-button for the lifting moment limiting device
- X 3 Y switching of the selector for the use of the 9°/10° function
- XP ON 4 XP OFF selector for the use of the crane standard or XP
- A 5 B selector for the use of the right control panel in configuration A or B
- OK 6 A + = control button
B -RPM = GAS +
- selector (enter) for control = ENTER L SET A
GAS - = -RPM B 7
- 8 H = free
- selector (various times) for control = A
starting the engine = B 9
- A INDEX 10 B = selector (index-return) for control
B = turning off the engine

14.2 Manoeuvres to unfold the crane into a working condition

The plate DE4452 indicates the sequence of the manoeuvres to be carried out to unfold and to fold the crane.

- Engage the power take off.
- Stabilize the vehicle (see details on Paragraph 13 “Manoeuvres and controls to stabilize the vehicle”).

By operating the corresponding levers:

- make sure that the extension booms and the outer ram are closed;
- lift the inner boom over the horizontal line;
- open the outer boom to the “horizontal” position;
- position the hook on the vertical line above the load.

14.3 Manoeuvres to fold the crane into the rest condition (see plate DE4452)

By operating the corresponding levers:

- fold the extension booms to their stroke end;
- lift the inner boom to its stroke end;
- fold the outer boom to its stroke end;
- rotate the crane until the arrows coincide (on the base and on the slew ring);
- fold the inner boom to its stroke end; the rest locating pin locates into its seat;
- re-position the outriggers to within the overall vehicle width as described on Paragraph 13.





fig. 18

16.1 Generality

- (!) Before manoeuvring the load, verify that the working area is suitable for your crane.

The lifting curves of the capacity plate indicate the maximum load that the crane can lift at a certain radius and at a certain height. To utilize the maximum capacity of the crane, it is necessary to position the inner boom as indicated on the capacity plate; the coloured symbols on the inner boom and column must coincide. During load handling, do not exceed the reach limits given, or the load indicated on the above mentioned charts. If the limits are exceeded, the load limiting device, allowing all manoeuvres, which reduce the lifted load within the permitted reach limits and forbid all other manoeuvres, will be immediately activated.

On the crane has been installed an electronic system to automatically control the maximum speed for moving the booms in relation to the load applied. With low loads, the control system allows the use of the nominal capacity of the pump, while the oil capacity available for the moving, is automatically and progressively reduced, at the increased loads.

The manoeuvres affected by this system are:

- rotation
- lift and descent of the inner boom
- lift and descent of the outer boom
- exit of the extension booms of the crane
- lift and descent of the jib (when fitted)
- exit of the extension booms of the jib (when fitted)

Lifting moment limiting device

A characteristic which permits the classification of cranes is their lifting capacity or maximum lifting moment. The moment is defined by the value obtained from the weight of the load to be lifted (**kg**) by its distance (**meters**) from the centerline of the crane rotation. The device called "lifting moment limiting device" preserves the crane structure from overloads, as it prevents any movement which increases the value of the moment up to the maximum established value.

16.2 "Electronic" lifting moment limiting device

This device utilises an electro-hydraulic system managed by an electronic logic that prevents any operation tending to cause an increase in the pressure induced by the load in the lifting rams (inner, outer rams of the crane and of the hydraulic extension, if fitted), up to the critical values. These values, which are not exceedable, determine the intervention levels and provide the data for setting the device.

The pressure values detected in the lifting rams are turned into electric signals by the transducers, and sent to the electronic logic of the device which determines the locking or unlocking of the controls concerned, according to the horizontal position of the crane outer boom (mercury level switch); only the controls allowing a reduction of the overload are enabled, while those increasing it are disabled.

The device features an electro-hydraulic control that does not allow the set value to be exceed, by deactivating the controls (levers in neutral position) commanded by the limiting device. When the controls are released (levers in neutral position) it's this electronic logic that handles which manoeuvres are disabled, according to the position of the crane outer boom and in overload condition, by sending electric signals to special micro-switches placed on the elements of the distributor.

(!) ATTENTION (!)

The presence of the lifting moment limiting device does not release the user from the obligation to respect what is indicated on capacity plates and lifting curves.

16.3 Control panel

The control devices are inserted in the push-button panel of the radio remote control.

For the picture list of the push-button panel of the radio see “Controls to operate the crane”.

If the warning light over the on radio button comes on, it confirms that the control unit has been activated.

!NOTE! In the absence of electric power all crane functions will be desactivated.

If during operation the yellow led placed on the side of the display comes on, 90% of the rated capacity has been reached.

If during operation the red led placed on the side of the display comes on, the activation value of the lifting moment limiting device has been reached.

Visual indicator yellow/red light

The control unit was up to 90% loading a graduated band of led lights to show the increased load, upon reach 90% a yellow led will be illuminated, upon reaching 100% and activation of the lifting moment limiting device a red led will be illuminated. The visual indicator located on the crane is shown in fig. 19.

Any hidden danger situation for persons must be audibly warned by pressing the push button of the audible alarm (on radio and audible alarm push button).

When there are serious, imminent and dangerous conditions for persons and things during load handling, operate on the **STOP** button, which isolates all crane functions and activate the intermittent audible alarm push button.




fig. 19

16.4 Load handling

Manoeuvres of the crane

Fig. 20a-b e 20c-d illustrate the configurations of the crane (and of the eventual hydraulic extension) with the manoeuvres allowed and not allowed by the device, in connection with the horizontal position of the crane and extension outer booms.

(!) ATTENTION (!)

In the overload condition, if you simultaneously effect one permitted and one non permitted manoeuvre you haven't movement. In the overload condition, before effecting a permitted manoeuvre, it is necessary to return all the levers to the neutral position.

(!) ATTENTION (!)

During load handling with the crane and with the crane and hydraulic jib, in vertical configuration or close, the operator must strictly refer to the loads indicated on the capacity plates since the limiting device shows to be not particularly sensitive with vertical lifts.

Crane with activated limiting device by the intervention of the crane or the hydraulic jib (overload condition) and with outer boom of the crane above the horizontal line fig. 20a-20b

Manoeuvres not allowed:

- Inner boom descent
- Outer boom descent
- Extension of the crane extension boom sections (*)
- Lift and descent of the hydraulic jib
- Extension of the extension booms section of the jib
- Winch rope lift
- Movement of the hydraulic accessories (**)

- NOTES:** (*) If the overload condition has been activated by the hydraulic extension, the extension of the crane boom sections is permitted.
(**) It is permitted only when coupled with permitted manoeuvres.

Manoeuvres allowed: all the manoeuvres that bring the load closer to the column and therefore the overload

- Rotation in both directions
- Inner boom lift
- Outer boom lift
- Re-entry of the crane extension boom sections
- Re-entry of the jib extension boom sections
- Winch rope descent

Crane with activated limiting device by the intervention of the crane or the hydraulic jib (overload condition) and with outer boom of the crane under the horizontal line fig. 20c-20d





Manoeuvres not allowed:

- Inner boom lift
- Outer boom lift
- Extension of the crane extension boom sections (*)
- Lift of the hydraulic jib
- Extension of the extension booms section of the jib
- Winch rope lift
- Movement of the hydraulic accessories (**)

- NOTES:** (*) If the overload condition has been activated by the hydraulic extension, the extension of the crane boom sections is permitted.
(**) It is permitted only when coupled with permitted manoeuvres.

Manoeuvres allowed: all the manoeuvres that bring the load closer to the column and therefore the overload

- Rotation in both directions
- Inner boom descent
- Outer boom descent
- Re-entry of the crane extension boom sections



- Descent of the hydraulic jib
- Re-entry of the extension booms section of the jib
- Winch rope descent

Crane with activated limiting device (overload condition) by the intervention of the load limiter of the winch

Manoeuvres allowed:

- Rotation in both directions
- Re-entry of the crane extension boom sections
- Re-entry of the jib extension boom sections
- Winch rope descent

Manoeuvres not allowed:

- all other movements

Crane without load applied and activated limiting device

The limiting device may intervene also during loadless crane operation following a pressure peak provoked by the attainment of the stroke end of the lifting ram at high speed. In this condition, reactivation of the crane commands by performing one of the manoeuvres is allowed by the system. If the limiting device intervenes when both the lifting rams are open and at stroke end, and the crane extension booms are fully folded, it is not possible to reactivate the commands, since the permitted manoeuvres (arm lifting and extension fully retracted) cannot be carried out, because of the actual configuration of the crane (outer boom above the horizontal). The device, in this case, allows the descent manoeuvres since it verifies that it was a peak pressure inside the lifting rams; the crane being loadless, thus these manoeuvres will be allowed.

Temporised exclusion device of the lifting moment limiting device

The activation of the exclusion device is permitted when the limiting device is activated and only in the case when it is impossible to carry out any of the allowed manoeuvres. This generally occurs when handling heavy and bulky loads, with the outer boom above the horizontal and the extension boom sections almost retracted.

(!) ATTENTION (!)

The activation of the exclusion system for the lifting moment limiting device can ONLY be operated when the extension booms of the crane and of the hydraulic jib (when fitted) are fully retracted.

The activation button of the excluding device, **only in the case of the crane**, are to be activated as follows:

- retracted the crane extension booms until stroke end and momentarily pressurise;
- maintain the command for the extensions boom until the red led of the button LMI placed on the control panel begins to flash;
- continue to keep the command for the extensions boom and press the exclusion device button, the flashing red light becomes fixed;
- release the lever commanding the extensions booms.

The permitted manoeuvre is the descent of the outer boom in order to bring it under the horizontal; remember that you have at your disposal **five (5)** seconds from the command operation to carry out the descent. After such period of time, wait at least **one (1)** minute in order to be allowed to carry out the manoeuvre once again.

The activation button of the excluding device, **only in the case of the hydraulic jib**, are to be activated as follows:

- retracted the extensions booms of the hydraulic jib until stroke end and momentarily pressurise;
- maintain the command for the extensions of the hydraulic jib boom until the red led of the button LMI placed on the control panel begins to flash;
- release the lever commanding the extensions booms of the hydraulic jib;
- within 3 seconds from releasing the lever commanding the extensions booms of the jib, retracted the extensions booms of the hydraulic jib until stroke end and momentarily pressurise (the red led turns off as soon as the re-entry begins);
- maintain the command for the extensions boom until the red led of the button LMI placed on the control panel begins to flash;
- continuous to keep the command for the crane extensions boom press the exclusion device button, the flashing red light becomes fixed;
- release the lever commanding the crane extensions booms.

The permitted manoeuvre is the descent of the outer boom in order to bring it under the horizontal; remember that you have at your disposal **five (5)** seconds from the command operation to carry out the descent. After such period of time, wait at least **one (1)** minute in order to be allowed to carry out the manoeuvre once again.

(!) ATTENTION (!)

Activation of the exclusion device of the lifting moment limiting device.

When the operator uses this device, it means that he wishes to override the lifting moment limiting device in order to make some manoeuvres (which would be impossible with the device active) that bring the moment to within the maximum level, but involve an overload condition. In such an emergency condition (where the lifting moment limiting device has been disabled), the operator, who is the main responsible for the machine safety, must:

- carefully consider the manoeuvres required to return to normal working conditions;
- calmly and carefully assess the type and scale of the hazards arising from these manoeuvres and the possible reaction of the crane (tipping over, frame overload, uncontrolled fall of the load due to a hydraulic system overload etc.);
- make all movements as slowly as possible to reduce the dynamic overload to the minimum.

16.5 Lifting moment limiting device for two working sectors

In case of one sector of the working area with reduced stability of the vehicle (e.g. sector in front of vehicle cab) the limiting device can be provided with a special function which allows to operate with a reduction of the intervention level. The reduction of the intervention level reduces the crane capacity values and this reduction value is defined in the vehicle stability calculation. Consequently the working area is divided in one sector (e.g. body side) where the crane works according to the capacity plate values and another sector (e.g. cab side) where it works with reduced capacity values. The device has consequently two intervention levels which are activated in relation to the sector of the crane working area always securing the vehicle stability.

(!) ATTENTION (!)

If the rotation stops by going through the working zone where the crane can operate according to the capacity plate values to the one where it can operate according to the reduced values, it means that one of the following conditions is reached:

- rotation of a load bigger than the one admitted in the reduced sector defined in the vehicle stability calculation;
- rotation without load applied but with (at least) one of the inner, outer rams of the crane or the jib (if fitted) extended and pressurised at the stroke end.

The following manoeuvres are allowed:

- the opposite rotation
- the manoeuvres allowed by the limiting device in relation to the position of the outer boom (positioned over or under the horizontal line).

16.6 Rotation limiting device

When a sector of the working area exists in which the stability is insufficient (for example in the area in front of the cab) the permitted arc of rotation is limited by means of an adjustable electro-hydraulic device which only allows operation within the safe area. (Warning: persist in the operation!)

When exceeding the "safe area" the rotation limiting device only allowing:

- the opposite rotation
- the manoeuvres allowed by the limiting device in relation to the position of the outer boom (positioned over or under the horizontal line).

If a reduction of capacity is necessary because of insufficient stability of the complete unit, new capacity plates must be fixed giving the derated capacity in accordance with the final stability test.

(!) ATTENTION (!)

Always check carefully that the vehicle is perfectly stable, paying special attention to the area immediately in front of the driver's cabin as this is usually less stable.

16.7 In the case of the appearance of the signal "ALARM" on the display of the control panel or of the radioreMOTE control or in case of an electrical failure.

In these cases, because of a fault, shown in the system, the crane is not functional any more. The checks that the operator can effect to reactivate the crane functions are the following:

- in case of an electrical failure check the connection of the feeding cables to the battery;
- in case of the appearance of the signal "ALARM" on the display of the push-button panel see Par. 15.7.1 and check if the fault can be resolved by the operator.

If the fault cannot be resolved, you must immediately go to a FASSI **authorized Center** after bringing the crane to its rest position in relation to the conditions explained in the paragraphs 15.7.2, 15.7.3.

16.7.1 Diagnostic (Alarms/Input/Output) LME vers. 4-5 UC 01-7

It is possible to install on the machine some operation improvements of the limiting device not yet described here. For this purpose compare the released version of the software installed on the machine (you can read it on the display when switching on) with the one in this paragraph's heading. For further explanations please refer to Fassi service network.

All the eventual problems that the electronic device can have are shown on the display of the control panel and they create the stop of all crane functions. The visualisation of the alarm must be reset pushing the button I.m.l.d. exclusion on the main box control panel, which bring again the display in the original screen showing the pressures only if the problem has been solved. As consequence of this, when appear an alarm signal it is necessary to solve the problem because only in this case will be possible to reset the display and reactivate the crane working.

ALARM CODES:

- 01 - electronic card alarm
- 02 - inner ram transducer alarm
- 04 - outer ram transducer alarm
- 06 - jib articulating ram transducer alarm
- 08 - proximity sensor alarm (central one off)
- 09 - proximity (lateral one off)
- 10 - mercury sensor level alarm (connector disconnected)
- 11 - mercury sensor level alarm (sensor defect)
- 12 - winch alarm
- 14 - microswitch on the inner ram distributor segment alarm
- 15 - microswitch on the outer ram distributor segment alarm
- 16 - microswitch on the jib articulating ram distributor segment alarm
- 17 - microswitch on the extension rams distributor segment alarm
- 18 - microswitch on the jib extension rams distributor segment alarm
- 19 - microswitch on the winch distributor segment alarm
- 20 - microswitch on the rotation distributor segment alarm
- 21 - 10A fuse alarm (fuse inside the main control panel protecting the emergency circuit)
- 22 - winch stroke end device alarm

Only for crane with slew ring:

- 30 - inconsistency of the rotation lever movement alarm
- 31 - inconsistency of the inner ram lever movement alarm
- 32 - inconsistency of the outer ram lever movement alarm
- 33 - inconsistency of the crane extension ram lever movement alarm
- 34 - inconsistency of the jib articulating ram lever movement alarm
- 35 - inconsistency of the jib extension ram lever movement alarm
- 36 - inconsistency of the winch lever movement alarm
- 40 - CAN-BUS reading alarm on unit FX003
- 41 - CAN-BUS reading alarm on unit FX004
- 42 - CAN-BUS reading alarm on radio remote receiver unit

MESSAGES

EXPLANATION

- | | |
|-------------------|--|
| "WINCH OFF" | - information for the activation of the winch up or down. |
| "WINCH CAL.ERROR" | - flashing warning (10 seconds each minute); it appears when the maximum detection of the winch adjustment with load is exceeded. |
| "STOP BOOM OUT" | - warning for the interruption of the extension boom exit because of a sudden variation of the cable tension. |
| "STOP JIB 25°" | - warning of not permitted activation of the lifting functions because of the activation of the maximum vertical operativity of the jib when it is complete with the 25° angle increasing. |
| "PLE" | - activation of the speed reduction for the use of the access platform. |

What to do in case of alarm**CODE REMEDY**

- 01 Take off the tension to the system and take on again the tension. If the problem remains, take off the tension to the system again, take on the tension and wait 12 minutes (12 minutes waiting time is a compulsory condition and needs to be checked with a watch), take off the tension to the system again, take on again the tension.
If the problem remains, you must immediately go to a FASSI **authorised Center**.
- 02 Check the connector of the pressure transducer.
If the problem remains, you must immediately go to a FASSI **authorised Center**.
- 04 See code 02.
- 06 See code 02.
- 08 Check if the red light on the proximity sensor is off and verify if the metallic band is rightly positioned.
- 09 See code 08.
- 10 Check that the connector of the mercury sensor level is not damage.
If the problem remains, you must immediately go to a FASSI **authorised Center**.
- 11 You must immediately go to a FASSI **authorised Center**.
- 12 See code 11.
- 14 See code 11.
- 15 See code 11.
- 16 See code 11.
- 17 See code 11.
- 18 See code 11.
- 19 See code 11.
- 20 See code 11.
- 21 Replace the 10A fuse at the nearest workshop after removing the carter and the cover of the main panel FX000. (See electric schematic Par. 5)
- 22 See code 11.

Only for crane with slew ring:

- 30 See code 11.
- 31 See code 11.
- 32 See code 11.
- 33 See code 11.
- 34 See code 11.
- 35 See code 11.
- 36 See code 11.
- 40 See code 11.
- 41 See code 11.
- 42 See code 11.

MESSAGES

"WINCH OFF"

"WINCH CAL.ERROR"

"STOP BOOM OUT"

"STOP BOOM UP"

REMEDY

Place the distributor bank lever controlling the winch in neutral position.

See code 11.

Place the distributor bank lever controlling the extension booms in neutral position. If the warning appears when the winch cable lifting stroke end is not reached, place in any case the lever in neutral position and then restart to operate.

Lifting functions not available; are authorized only descent functions.

To verify the right working of the different inputs it is possible to use the display in the "INPUT" menu.

16.7.2 Temporary OVERRIDE-REACTIVATION for the crane functions in case of the appearance of the signal “ALARM” on the display of the push-button panel


Note: If the alarm doesn't involve components which control the distributor, it is possible to re-close the crane using the push-button panel of the radio remote control.

(!) ATTENTION (!)

These manoeuvres can be effected where the lifting moment limiting device has been disabled, and then can involve an overload condition. In such an emergency condition, the operator, who is responsible for the machine safety, must:

- carefully consider the manoeuvres required to return to normal working conditions: it is however compulsory to effect the re-entry of the extension booms at first,
- calmly and carefully assess the type and scale of the hazards arising from these manoeuvres and the possible reaction of the crane (tipping over, frame overload, uncontrolled fall of the load due to a hydraulic system overload etc.);
- make all movements as slowly as possible to reduce the dynamic overload to the minimum.

Reactivation of the crane functions using the push-button panel of the radio:

Keeping pressed the exclusion push-button () of the limiting device on the push-button panel, operate on the lever of the movement to be effected.

After such emergency operations and prior to re-use of the crane, you must immediately go to a FASSI authorised Center for reactivation of the crane functions and re-sealing of the device.

- (!) Interferences with the valves or removal of the lead seal release the FASSI GRU IDRAULICHE from any responsibility and invalidate the warranty.

16.7.3 Temporary OVERRIDE-REACTIVATION for the crane functions in case of an electrical failure, out of order of the radio remote control, or of the appearance of the signal “ALARM” on the display of the push-button panel (in this case, we cannot reactivate the crane functions).

On the distributor it has been installed an **emergency lever** to be used in the event of a black-out, electrical or hydraulic malfunctions. Only In these situations it is permitted to remove the lead seal placed on the tap lever and place it in the closed position.

For the access to the tap lever remove the cover 1 (fig. 21) placed under the protection guard of the distributor by unscrewing the two fixing screws (10 mm hexagonal spanner).

- (!) When the electric power is reestablished, remember to put the lever in the opened position.

(!) ATTENTION (!)

Activation of the emergency lever.

This activation prevents the operation of the lifting moment limiting device, consequently, the operation under such conditions can involve an overload condition. In such an emergency condition (where the lifting moment limiting device has been disabled), the operator, who is responsible for the machine safety, must:

- carefully consider the manoeuvres required to return to normal working conditions: it is however compulsory to effect the re-entry of the extension booms at first,



fig. 21

- calmly and carefully assess the type and scale of the hazards arising from these manoeuvres and the possible reaction of the crane (tipping over, frame overload, uncontrolled fall of the load due to a hydraulic system overload etc.);
- make all movements as slowly as possible to reduce the dynamic overload to the minimum.

After such emergency operations and prior to re-use of the crane, you must immediately go to a FASSI authorised Center for testing the structure and re-sealing of the device.

(!) **Interferences with the valves or removal of the lead seal release the FASSI GRU IDRAULICHE from any responsibility and invalidate the warranty.**









fig. 22



In case of an electrical failure, all the control levers of the push-button panel of the radio-remote and the emergency control cannot be used and then, it is necessary operate directly the distributor (fig. 22).

For the access to the distributor remove the cover 2 (fig. 22) by unscrewing the five fixing screws.

The column controls must only be used in an emergency and only to bring the crane to its rest position.

Be very careful at the manoeuvre of rotation because of the residual danger of crushing.

During emergency manoeuvres, the operator, when it is possible should be assisted by a second trained person who can intervene if necessary (Eg.: positioning the lever D of the deviator (E - E/S) on E/S, by using then the deviator crane-outriggers like interruption control of emergency.

(!) **ATTENTION (!)**

The presence of the lifting moment limiting device does not release the user from the obligation to respect what is indicated on capacity plates and lifting curves.

(!) **CAUTION DANGER (!)**

On the outer boom there is a mercury capsule (mercury level switch) duly protected and provided with the following warning stickers.



DE1680



DE1679

Contiene mercurio: smaltire secondo le leggi in vigore

Es hat quecksilber: bitte beseitigen so wie gesetzlich

Mercury inside: scrap following laws in force

Contient du mercure: recycler selon les lois en vigueur

Hg



Mercury is extremely toxic. In case of replacement and/or scrapping, dispose of or recycle the capsule containing mercury with maximum care, and in accordance with the national regulations in force.

(!) **ATTENTION (!)**

Do not walk on... DE1679

Do not use water to extinguish fire! DE1680

16.8 XP DEVICE

This device can be activated only through the push-button panel of the radio remote control, see Par. H0 “Controls to operate the crane”.

The XP device works on the principle of an increase in the lifting capacity of the crane with a reduction in the dynamic effect achieved with a reduction in the speed of certain movements.

The XP device can be used, not just to increase the capacity crane:

- but to exploit the reduction in the speed when moving a load that must be positioned with precision.
- and to exploit the variation in the lifting moment limiting device adjustment parameters to exit from a critical situation when moving the load (overcoming of the 90% or intervention of the lifting moment limiting device).

(!) ATTENTION (!)

The rating plates relevant to the XP device are marked F...XP.

16.8.1 Activation and instructions for use of the XP/V device

You operate the XP device only from the console of the radio remote control by using the appropriate selector (fig. 22a).

RScanreco radio remote control

You operate on the XP/ON-XP/OFF selector (fig. 22a) on the XP/ON position.

The activation of the XP device is indicated with the mark XP displayed up on the right of the control panel.

(!) WARNING (!)

It is recommended to release the crane controls (levers of the control console in neutral position) before activating or deactivating the **XP** device because of the variation of speed is considerable and immediate; carefully operate the controls.

See paragraph 14 of the USE AND MAINTENANCE MANUAL for details of “Controls to operate the crane”

See paragraphes 16 of the USE AND MAINTENANCE MANUAL for details of “Lifting moment limiting device”

The activation of the XP device on cranes with free rotation or with rotation limiting device produces:

- an increase in the capacity of the crane
- a reduction in the speed of rotation without increasing the torque
- a reduction in the speed of lifting and lowering the inner boom, outer boom and of the jib boom (when fitted)
- speed of the extension booms, bucket and the rotator.
- allows normal speed and lifting capacity of the winch.

SCANRECO RADIO REMOTE CONTROL



fig. 22a

The activation of the XP device on cranes with lifting moment limiting device for two sectors produces:

- in the “stable” zone working area, the same effect for crane with free rotation
- in the “unstable” zone working area, a reduction in the speed without the increase in capacity.

Activation of the XP device when the 90% of the capacity has been reached

- the yellow light on the "led" band of the push-button panel goes off
- allowing the manoeuvres that increase the lifting moment, you then have the repeat of the yellow "led" band and red "led" band of the warning lights again.

Activation of the XP device after the lifting moment limiting device block

- A)** The block continues:
- the crane must be reset
- B)** The red "led" band of the warning light switches off and the yellow "led" band of the warning light usually comes on.
- the crane controls are enabled. Acting with the manoeuvres that increase the lifting moment, you get the yellow and red warning lights again.

16.9 IMC AND ADC DEVICES

The IMC (Integrated Machine Control) device is an electronic brain that processes real-time information coming from the peripheral sensors and from the crane electro-hydraulic systems; therefore it allows control of all functions and movements with precision, fluidity and safety.

The ADC (Automatic Dynamic Control) device controls the dynamics of the movements providing the maximum speed available subject to the applied load.

17.1 Generality

The crane, in load condition H1B3, can be provided with implements such as:

- Manual extensions
- Winches
- Hydraulic extensions
- Personnel baskets
- Clam 'shell buckets
- Augers

- (!) When using an implement it is always necessary to check that its weight, dimension and capacity is matched to the crane performances.
For further information please refer to **FASSI GRU IDRAULICHE**

Warning and norms for crane use also apply for hydraulic implement use.


Before using a personnel basket it is necessary to provide the crane with the safety devices requested by the local norms in force, EN280 in Europe, and prior to use of the crane it has to be tested and inspected in accordance with the local legal requirements.

- (!) When the crane is fitted with implements or laid on the truck body it is necessary to check they are locked to assure the impossibility of accidental movements and that the led signalling maximum obstruction in height (if fitted) confirms the correct positioning of the crane.
- (!) The crane can operate, intermittently and not continuously, with lifting devices other than the hook, only on loose and light materials (not on scrap iron).

(!) ATTENTION (!)

In case of using the crane with lifting devices other than the hook, the access to the working area at the persons must be prevented.

The dimensions and the capacity of the implements must be proportioned with crane performances.



(!) WARNING (!)

CRUSHING (F) OR PUSH (F) MANOEUVRES ARE NOT PERMITTED.

17.2 Hydraulic connections for implements - supplementary hoses.

(!) WARNING (!)

To ensure that the control corresponds to the implement movement, hydraulic connections are symmetrically fitted with coupling unions. Never invert such positions: movements inversion as well as operating difficulties or unusual overload with implement itself could occur.

NOTE

When using coupling unions it is necessary to verify that there is no trace of soil, dirt etc. on the unions and inside the seats so as to avoid the oil contamination and consequently wear the tightening " surface of unions or ram seals.

17.3 Oil cooler (heat exchanger)

The crane is equipped with an oil cooler (air-oil heat exchanger) to prevent damage caused by an excessive increase of the oil temperature.

NOTE

When working in a low temperature climate, we recommend to bring the hydraulic oil up to working temperature prior to starting work, This is best done by operating the crane thru all its functions ram stroke end.

(!) WARNING (!)

The heat exchanger openings must be kept clear and clean. At no time should it be covered.

18.1 Generality

These are additional extensions, which are placed in the hydraulic extensions of the crane and of the hydraulic jib and secured by locking pins.

Manual extensions have a maximum capacity independent from the crane configuration as shown on the capacity plates.

(!) ATTENTION (!)

Manual extensions can be extracted from the rest position and be operative, once the security pins have been removed, with the outer boom in sliding position.

(!) ATTENTION (!)

- Do not stand in front of stabilisers during operation!
Operate from a lateral position in respect of the extension movement of the manual extensions; operation from the frontal position is dangerous.
- Verify that the area is suitable for this operation and there are no unauthorized persons in the working area.
- Do not permit the extension to slide out at speed as this will damage the stroke end stops.
- Do not try to align the holes (slots) for the locking pins with your fingers; always use a suitable tool.
- When manual extensions are in place, fit the locking pins and secure them with the check pins to prevent accidental escape.

(!) Always remember that when operating with implements, their tare weight must be deducted from the capacity of the crane.

18.2 Lifting moment limiting device “ELECTRONIC” for the manual extensions (valid starting from the version 3.0 of the software)

HOW TO CONTROL THE LOAD HOOKED ON MANUAL EXTENSIONS.

This procedure aims to calculate the weight applied on the manual extensions. It is necessary to apply the same procedure **EVERY TIME** you use the manual extensions.

For its correct execution, follow meticulously the instructions reported **HERE**.

The extension limiting device **IS NOT ALWAYS ACTIVE**; on the contrary of the crane limiting device, it responds about lifting a load only if **QUESTIONED**, therefore only if you enable the procedure. Remember that the procedure is manual. In any case always refer to the capacity plates of the crane.

The limiting device for manual extensions, when interrogated, compares the real weight applied on the lifting hook (inclusive of all the accessories attached) with the value reported on the capacity plates. Such evaluation is effective only during the execution of the procedure, therefore it is prohibited to add weight or replace loads after the procedure is completed; in such case the procedure shall be executed again from the start.

In the case one or more manual extensions are added or removed with respect to the initial installation, it is **COMPULSORY** to have the crane initial configuration file modified accordingly (See Authorised Shops).


Before activating the procedure, extend and lock by a pin not only the manual extension you intend to use but also the preceding ones.

PANELS OF THE RADIO-REMOTE CONTROL

Figure A (left side)



Figure B (right side)



HOW TO PREDISPOSE THE USE OF MECHANICAL EXTENSIONS ON CRANE OR ON JIB

Note: In case of crane with slew ring and top seat, all the procedures mentioned below can be executed from both the control panel and the radio-remote control.

1. Initial display (Fig. 1)

Starting from the standard menu of the electronic lifting moment limiting device displaying the pressures of the lifting rams (fig. 1), keep the “F1” key (control panel), or the “+” and “ENTER” key (radio-remote control with the selector on “A”, fig. A and B) pressed for some seconds.




fig. 1



fig. 1

2. Choice the installation of the manual extensions on Crane or on Jib.(Fig. 2)

If the crane features the installation of the manual extensions both on the crane and on the jib, after the initial display, when you keep the “F1” (control panel) or “+” and “ENTER” key pressed (radio-remote control), the program displays the message illustrated in Figure 2.



fig. 2



fig. 2

Use the “+” button to select JIB if in the actual configuration the manual extensions are mounted on JIB or CRANE if the manual extensions are mounted on the crane.

3. Message “M1 - M2 - M3” (fig. 3)

After having pressed the above mentioned keys, the message illustrated in Fig. 3 will be displayed.




fig. 3



fig. 3

At this point, through the "+" button, select the correct number of the manual extension at the moment in use (M stands for manual and 1, 2 and 3 indicate the number of the manual extensions). Select the number of the manual extension you want; that number starts blinking. You can select only the manual extensions that have been installed: i.e. if only one manual extension is installed, by pressing the "+" key, only the M1 extension will start flashing. To confirm your choice, press once the "F1" key (control panel) or "ENTER" (radio-remote control); you'll access the section dedicated to the system configuration

4. Message “K1 - K2 - K3 - K4” (fig. 4)

[paragraph to read only in case of manual extensions installed on Jib and not on Crane]




fig. 4



fig. 4

If you press the "ENTER" key with the manual extensions mounted on the jib, the screen of Fig. 4 will be displayed.

Therefore we can choose the most convenient configuration among the following:

K1 Outer booms of the crane totally re-entered and jib extensions as you like

K2 Outer booms of the crane as you like and jib extensions totally re-entered

K3 Outer booms of the crane totally extended and jib extensions as you like

K4 Outer booms of the crane as you like and jib extensions totally extended

Select the desired configuration using the * button to move among the various options. Confirm your selection by pressing the "F1" (control panel) or "ENTER" (radio-remote control) key. If the hydraulic jib boom is not at its stroke end, the message at point 3 will be displayed; otherwise the message "F1 TO START" is visualised.

5. Message “FC P2” (fig. 5)

Note: do not hang any load on the hook.

This means that the outer ram must be positioned at its stroke end (if it is already in that position this message won't appear), using the lever until the next screen is displayed.




fig. 5



fig. 5

6. Message "FC P3" (fig. 6)

[paragraph to read only in case of manual extensions installed on Jib and not on Crane]

Note: do not hang any load on the hook.

This means that the jib outrigger must be positioned at its stroke end (if it is already in that position this message won't appear), using the lever until the next screen is displayed.




fig. 6



fig. 6

7. Message "F1 TO START" or "F1 / ENTER START" (Fig. 7)

At this point the display will visualize the message "F1 TO START" (control panel) or "F1/ENTER START" (radio-remote control). Press the "F1" (control panel) key or "ENTER" (radio-remote control) to continue.



fig. 7



fig. 7

8. Message "UP P1" (see fig. 8)

Note: do not hang any load on the hook.

It requires the activation of the inner boom lifting to eliminate an overpressure at the lifting ram bottom (the manoeuvre is activated but the crane does not move since all the movements are disabled).

Note: set the lever of the inner ram at its stroke end to simulate the lifting and keep it like this for at least three seconds.




fig. 8



fig. 8

9. Message "START LOAD P1" (vedere Fig. 9)

Releasing the lever in neutral position the display visualises the message START LOAD P1.

It requires the slow lifting of the load using the inner ram. This allows to haul it up from the ground in order to calculate the weight which will be pointed out releasing the lever in neutral position.




fig. 9



fig. 9

10. Message “LOAD OK” (fig. 10)

This message confirms that the load does not exceed the lifting limits of the crane and of the manual extension selected.



fig. 10



fig. 10

CLOSING OF THE PROCEDURE

All the crane functions will still be kept disabled. To start operating press the “INDEX” key (control panel fig. 10, or radio-remote control fig. D always with the selector in position “A” fig. C).



Figure C



Figure D

For an overall view of the procedure, we attach the diagrams showing all the passages and messages that can be displayed during the procedure according to the various situations that may take place.

The script "EXIT" in the block diagram allows to exit the procedure.

FURTHER MESSAGES

After releasing the lever in neutral position you can find the following messages

If you keep pressed the "F2" key "F2" on the control panel or "LMI" on the push-button panel, it is possible to have an indicative evaluation of the weight applied on the hook (fig. 11).




fig. 11



fig. 11

a. “PRESSURE ERROR” (see fig. 12)

It warns you that the system found an error in the pressures of the lifting booms. The whole procedure must be restarted.



fig. 12




fig. 12

b. **“NO LOAD” (fig. 13)**

In this case the load exceeds the max lifting value of the selected manual extension (it could still be on the ground). Unhook the load since it cannot be lifted using the selected manual extension. As in the preceding case, if you keep pressed the "F2" key, it is possible to have an indicative evaluation of the weight applied on the hook (fig. 11).



fig. 13



fig. 13

c. **“NO SPEED” (fig. 14)**

The load has been lifted too quickly; the whole procedure must be repeated from the beginning. The "LMI" key on the push-button panel or "F2" key on the control panel is disabled because it has not been possible to calculate the applied weight. Press INDEX on the push-button panel or "F1" key on the control panel to exit the procedure and go back to the standard operation. Put down the load on the ground and repeat the whole procedure from the beginning.



fig. 13



fig. 13

d. **“NO LOAD CRANE!” (Fig. 15)**

This message informs that the lifted load exceeds the max limit value of the crane/jib, irrespective of the manual extensions, so that the load cannot be lifted in this configuration due to the crane/jib overload. Also in this case the load must be either removed or approached to the crane, and handled in a different way without using the selected manual extension. Moreover the whole procedure must be repeated from the beginning.





fig. 13




fig. 13

Electric schematic - crane with manual extensions



Electric schematic - crane with jib and manual extensions on jib



20.1 Generality

The hydraulic jibs, foldable behind the cab, are additional booms, with articulation and with one or more extension booms to be fitted to the last extension boom of the crane; on request the manual extensions can be installed on the extension booms of the jib.

NOTE

The weights reported in the table are indicative and can vary in relation to the fittings.

The jibs are fitted by means of the insertion of the extension connecting boom into the crane extension boom; the fixing to the crane is obtained through locking pins. The hydraulic connection to the supplementary functions of the crane, is through quick couplings.

(!) Warnings and norms for crane utilisation apply also for hydraulic jibs use.

(!) ATTENTION (!)

The loads shown on the capacity plates which concern the configuration of the crane with hydraulic jib, refer to the hydraulic jib and consequently they are the same whether the crane has its extension booms retracted or extended.

(!) Warnings and norms for manual extensions are indicated at Paragraph 18.

(!) ATTENTION (!)

It is recommended to employ lifting means adequate to the weight of the load and radius of the extensions; during this operation the operator is responsible for the machine safety. The slings or the cables used for handling the load should have the adequate capacity and length; try to avoid the load overturning by having one length passed through itself and the other one through the hook.

20.2 Identification of the hydraulic jib

The model, the version of the crane, the year of construction and the serial number are stamped on the hydraulic jib (fig. 28) in the following sequence:

L102*03*001

A B C

A = model

B = year of construction

C = serial number

20.3 Nomenclature of the hydraulic jib

Pos. Description

1. Connecting boom
2. Locking pins
3. Jib outer ram
4. Jib outer boom
5. Boom extension rams
6. Extension booms
7. Manual extension (on request)
8. Lifting hook




fig. 28

20.4 Manoeuvres to unfold the jib in working condition

- Operate as described to put the crane in working condition (paragraph 14.2).

By operating the corresponding levers:

- open the outer boom of the jib;
- extend the jib outer boom sliding sections;
- position the hook on the centerline of the load.

20.5 Manoeuvres to fold the jib in rest condition

By operating the corresponding levers:

- re-enter the hydraulic sections of the jib and of the crane;
- lift the inner boom to its stroke end;
- re-enter the outer boom of the jib and of the crane to its stroke end;
- operate, as described, to fold the crane in rest position.

(!) WARNING (!)

Always check and record the overall height of the crane in the folded position or in laid position in the body or on the load.

Always respect and pay proper attention that the load and dimension limits are in conformity with the road regulations.

20.6 Operations to remove the hydraulic jib from the crane

By operating the corresponding levers:


- re-enter the jib outer booms sliding sections to their stroke end;
- extend the crane outer ram to its stroke end;
- extend (of at least 1 - 1,5 m) the crane outer booms sliding sections;
- re-enter the outer ram of the jib and the inner ram of the crane to obtain the two rest brackets of the jib, either lay on the ground, or on the truck body or, if possible, on a specific rest trestle;
- remove screwing the locking pins;
- re-enter the outer booms sliding sections of the crane to free the first boom of the crane jib;
- disconnect the jib from the hydraulic circuit of the crane operating on the quick couplings.

- (!) Assure that the hydraulic jib is adequately stripped to avoid side turnover.

20.7 Operations to mount the hydraulic jib on the crane

By operating the corresponding levers:


- place the extension on the vehicle or on the ground in the direction of the movement of the extension booms;
- extend the crane outer ram to its stroke end and position the extension booms of the crane not too close to the first boom of the jib in order to allow the lining-up manoeuvres and the connection of the hoses;
- connect the jib hoses to the hydraulic plant through coupling unions, following indications of Paragraph 17.2, Hydraulic connections for implements - supplementary hoses;
- operate the outer ram of the jib and the inner ram of the crane in order to align the extension booms of the crane and the first boom of the jib thus allowing their connection;
- eventually repeat the previous operation until the fixing holes are aligned, working on the extension booms of the crane;
- insert the lock pin into the fixing holes and secure it with the check pin.

	FASSI GRU IDRAULICHE SpA 24021 ALBINO (BG) ITALIA - Via dei Carmelitani, 2 Tel. + 39 35 77.64.00 - Fax + 39 35 75.50.20	INSTRUCTIONS FOR SAFE USE OF THE CRANE	DE4236
<p>1 Only authorized persons are permitted to operate the crane.</p> <p>2 The crane must be used on firm, level ground.</p> <p>3 Check that the vehicle hand brake is on and that the wheels are chocked.</p> <p>4 Before operation make sure that:</p> <ul style="list-style-type: none"> - no-one is within the working area of the crane; - the safety devices are in place and operative; - the minimum safe working distances from power lines are observed; - the load is correctly slung and hooked. <p>5 Stabilize the vehicle with the outriggers, making sure that:</p> <ul style="list-style-type: none"> - the lateral supports are fully extended; - the wheels are in contact with the ground and the suspension is not completely unloaded. 			

- 6** Use the crane in accordance with the use and maintenance manual, making sure that:
- the load and radius are within the maximum limits shown on the crane capacity plate;
 - the crane is used progressively avoiding sudden load movements;
 - swinging or dragging of the load is avoided;
 - the load is lifted before rotating.
- 7** When using implements protect the working area with a barrier.
- 8** The vehicle/crane are not left unless the power take off is disengaged and the load is on the ground.
- 9** Before driving the vehicle ensure that the outriggers are fully retracted and re-entered, the safety taps closed and the crane is in the folded position.


DE 4236

Instruction plate and safety norms


ATTENZIONE: PRIMA DI AZIONARE LA GRU E' OBBLIGATORIO METTERE IN OPERA GLI STABILIZZATORI.
WARNING: BEFORE OPERATING THE CRANE IT IS COMPULSORY TO EXTEND THE OUTRIGGERS.
ATTENTION: AVANT D'UTILISER LA GRUE IL EST OBLIGATOIRE DE METTRE EN FONCTION LES STABILISATEURS.
ACHTUNG: VOR INBETRIEBNAHME DES KRANS MUESSEN DIE ABSTUETZUNGEN AUSGEFAHREN.
ATENCIÓN: ANTES DE ACCIONAR LA GRUA ES OBLIGATORIO ESTABILIZAR EL VEHÍCULO.
ATENÇÃO: ANTES DE UTILIZAR A GRUA É OBRIGATÓRIO COLOCAR EM FUNCIONAMENTO OS ESTABILIZADORES.
DE2327

DE 2327

Warning plate to stabilize the vehicle before using the crane

**DE 4452**


Instruction plate to fold the crane into the rest condition

**DE 4491**




Do not operate from the frontal position, to extend the outrigger supports

**DE 2100**

Danger plate for crushing of lower limbs



Instruction plates
to stabilize the vehicle


LEVERS CD**LEVER C****LEVERS CD**




DE 1681
Greasing points with brush




DE 1682
Greasing points at pressure



DE 1686
Do not walk or stop under a suspended load



DE 1683
Do not operate in proximity of electric high-tension lines




DE 2361
Do not operate in proximity of electric high-tension lines

**DE 1679**

Do not walk on...

**DE 1680**

Do not use water to extinguish fire

**DE 1574**Do not weld the fixing
rods